


Triple Combi TV SERVICE MANUAL

CHASSIS: MV-033A

MODEL: Multiplex 72

CAUTION

BEFORE SERVICING THE CHASSIS,
READ THE SAFETY PRECAUTIONS IN THIS MANUAL.










Triple Combi TV SERVICE MANUAL




CONTENT

| SAFETY INSTRUCTIONS | 1-2 |
|-------------------------|-----|
| SERVICING PRECAUTIONS | 1-4 |
| SPECIFICATION | 1-5 |
| DESCRIPTION OF CONTROLS | 1-8 |

CHASSIS: MV-033A

MODEL: Multiplex 72

DESCRIPTION OF CONTROLS



All the functions can be controlled with the Communicator. Some functions can also be adjusted with the buttons on the front panel of the set.

Communicator

Before you use it, please select TV, VCR or DVD function by pressing the TVCR or DVD buttons.

1. I/II

selects the language during dual language broadcast. selects the sound output (option).

2. SLEEP

sets the sleep timer.

3. VCR BUTTONS

controls a LG video cassette recorder. For further details, see the 'VCR Operation' section.

4. DVD BUTTONS

controls a LG DVD player.

For further details, see the 'DVD Operation' section.

5. RESET

When Communicator does not work, reset the Communicator by pressing the reset point with sharp one.

6. POWER

switches the set on from standby or off to standby.

7. NUMBER BUTTONS

switches the set on from standby or directly select a number.

8. MENU

selects a menu.

9. ▲ / ▼ (Programme Up/Down)

selects a programme or a menu item. switches the set on from standby.

√ / ► (Volume Down/Up)

adjusts the volume.

adjusts menu settings.

OK

accepts your selection or displays the current mode.

10. MUTE

switches the sound on or off.

11. ARC (Aspect Ratio Control)

changes the picture format.

12. TVCR / DVD

selects to control a LG video cassette recorder or DVD player.

13. EJECT

Open or close the disc tray. ejects the tape.

14. PSM (Picture Status Memory)

recalls your preferred picture setting.

15. SSM (Sound Status Memory)

recalls your preferred sound setting.

16. TV/AV

selects the remote operating mode. clears the menu from the screen. switches the set on from standby.

17. TELETEXT BUTTONS (option)

These buttons are used for teletext. For further details, see the 'Teletext' section.

18. LIST

displays the programme table.

19. Q.VIEW

returns to the previously viewed programme. selects a favourite programme.

COLOURED BUTTONS: These buttons are used for teletext (only TELETEXT models) or programme edit.

Internal generator charge

The communicator can be charged with the internal electric generator. To charge the communicator do the followings;

1. In first use,


20 rotation of the handle in the arrow direction as picture below -> waiting for one minute -> 20 rotation again -> waiting for one minute again -> 20 rotation again -> beginning to use

2. In usual use

20 or 25 rotation -> resuming to use




Note: Do not rotate the handle too rapidly for the protection of the communicator.



Front panel

Shown is a simplified representation of front or side panel. Here shown may be somewhat different from your set.



Side panel

- MAIN POWER (ON/OFF) switches the set on or off.
- 2. STOP
 Stops playback for DVD player.
- PLAY Starts playback for DVD player.
- OPEN/CLOSE
 Opens or closes the disc tray.
- 5. **DISC TRAY**Places a disc on the disc tray.
- 6. LED (Light Emitting Diode) DISPLAY
- 7. CASSETTE COMPARTMENT Inserts a video cassette tape here.
- STOP/EJECT stops the tape during playback or recording or ejects the tape.
- 9. ▲ / ▼ (Programme Up/Down) selects a programme or a menu item. switches the set on from standby.
 ◄ / ► (Volume Down/Up) adjusts the volume. adjusts menu settings.

10. REC/ITR

starts a manual recording or instant timer recording.

11. POWER ($^{\circ}$ /I) switches the set on from standby or off to standby.

12. COMMUNICATOR SENSOR

Note: Only use the supplied Communicator. (When you use others, they'll be not able to function.)

13. HEADPHONE SOCKET (option)Connect the headphone plug to this socket.

14. AUDIO/VIDEO IN SOCKETS (AV2)

Connect the audio/video out sockets of external equipment to these sockets.

S-VIDEO/AUDIO IN SOCKETS (S-Video) (option)

Connect the video out socket of an VCR to the **S-VIDEO** socket.

Connect the audio out sockets of the VCR to the audio sockets as in AV2.

15. STANDBY / REC/ITR / TIMER REC INDICATOR

ADJUSTMENT INSTRUCTIONS

1. APPLICATION RANGE

These adjustment instructions is applied to MV-033A chassis.

2. Notes

2.1. Because this is a cold chassis, it is not necessary to use an isolation transformer.

But operate it using a transformer between the power supply line and chassis input to prevent electric shock and to protect the test instrument.

- 2.2. All adjustment must be done in correct sequence. However, for the better productivity, it can be changed in pre-permitted range.
- 2.3. Environment conditions : If not specified, it must be done in following conditions.


1) Temperature : 25° C \pm 5 $^{\circ}$ C 2) Humidity : $65 \% \pm 10 \%$

- 2.4. Power supply of a SET which is adjusted is AC110-240V, 50/60Hz.(EU model : AC230V,50HZ)
- 2.5. If not specified, the receiver must be operated for more than 20 minutes prior to the adjustment.

2.6. Signal

Receive the standard color signal. (65dB $\pm\,$ 1dB uV) LG standard signal means the digital pattern PAL-B/G 05CH.

3. DECK Line Adjustment.(VCR DECK Part)



<Fig1> Adjustment Position

3.1. P2/P3 Pre-Adjustment


3.1.1. Necessary Instrument

- 1) PAL SP Normal TAPE
- 2) OSCILLOSCOPE
- 3) 10:1 PROBE : 2 PIECES
- 4) SPECIAL NUT DRIVER (for P2/P3 Control)

3.1.2. Adjustment

1) Play the PAL standard Tape(SP).

- Connect to J261(H/SW) the OSCILLOSCOPE(CH-1) on the MAIN1 PCB.
- Connect to J219(RF) the OSCILLOSCOPE(CH-2) on the MAIN1 PCB.
- 4) With observing the RF envelope waveform, adjust P2, P3 until it becomes the waveform C.
- 5) Check the envelope waveform is in the maximum size by pressing the TRK UP(+).



<Fig2> P2/ P3 Adjustment Waveform

3.2. CTL/AUDIO LEVEL ADJUSTMENT

3.2.1. NECESSARY INSTRUMENT

- 1. CTL TAPE
- 2. PAL SP Standard TAPE(for Audio level adjustment)
- 3. OSCILLOSCOPE
- 4. 10:1 PROBE: 2 PIECES
- 5. RMS METER(for Audio level adjustment)

3.2.2. CTL ADJUSTMENT

THIS ADJUSTMENT MUST BE DONE WHEN THE UNCONTROLLED DECK IS WAREHOUSED.

- 1) Connect the OSCILLOSCOPE to J101(CTL)
- 2) After playing the CTL control tape, make sure the CTL waveform range is From 1.5:1 to 2.5:1.


If it is out of range , adjust CTL waveform to the following procedures.

- If is over 2.5:1, lower the head height. After turning the height adjust screw counter-clockwise to adjust its level from 1.5:1 to 2:1. Check the tape location at P4. Readjust the TILT.(2:1)
- ¤Łlf is under 1.5:1, heighten the head height. After turning the height, adjust the screw clockwise to adjust its level from 2 : 1 to 2.5 : 1. Check the tape location of P4. Readjust the TILT.(2:1)
- Play the standard tape and adjust the azimuth screw right and left by using the oscilloscope and level-meter to maximize the audio sound.

Adjust the azimuth screw & the height adjust screw at the same time because they have mutual relationship. (Check CTL again after the adjustment)

*A/C head adjustment order

Height adjust screw->check the TILT->azimuth screw->check CTL



<Fig3>

3.2.3 AUDIO LEVEL Checking and adjustment

- Connect "+" terminal of RMS meter(Auto level meter) to C392 on the main PCB Audio out and "-" terminal to GND.
- Check that if audio level of RMS meter satisfies with the spec, If audio sound is weak, adjust the A/C head azimuth screw.
- 3) Audio level spec 1K :0.5 \pm 0.1Vrms 6K :1KHz \pm 1.5dB

ADJUST PERIOD (6.5H = 412us) PG ADJUST WAVEFORM *CAUTION: SET THE TRIGGER MODE OF OSCILLOSCOPE TO DC

<Fig4>

3.3. X-DISTANT/P2,P3 ADJUSTMENT

3.3.1. NECESSARY INSTRUMENT

- 1) SP PAL TAPE
- 2) OSCILLOSCOPE
- 3) 10:1 PROBE: 2 PIECES
- 4).SPECIAL DRIVER FOR ADJUSTMENT(P2,P3,X-DISTANT(NUT),AUDIO(NUT))
- 5) RMS METER(AUDIO LEVEL METER)

3.3.2. ADJUSTMENT PREPARATION

- 1).Connect oscilloscope(CH-1) to J261(H/SW) on main PCB. (Use for trigger of CH-2)
- Connect oscilloscope(CH-2) to J261(RF) on main PCB. (Use waveform of CH-2)
- 3) Play by inserting SP PAL TAPE. (2HD:normal tape)
- After the picture is appeared, make initial condition by pressing the tracking adjustment up(+) button of the remote controller.

3.3.3. X-DISTANCE ADJUSTMENT

- Turn the X-distant adjust groove of the deck right and left to maximize the scope waveform.
- 2) Check that if waveform satisfies with the linearity by pressing TRK Up(+) and Down(-) button.
- 3) Tighten the X-distant adjust screw.

3.3.4. P2/P3(RF LINEARITY) CHECK & ADJUSTMENT

- Adjust p2 & p3 so that the RF envelope waveform of the oscilloscope becomes C in figure 2.
- Check if the envelope waveform becomes maximum by pressing TRK Up(+),Down(-) button one step.

3.4. PG ADJUSTMENT

Adjust it after finishing controlling the Deck.

3.4.1.NECESSARY INSTRUMENT

- 1) SP PAL TAPE
- 2) OSCILLOSCOPE
- 3) 10: 1 PROBE: 2 PIECES

3.4.2. ADJUSTMENT

- 1) Insert and play the SP PAL TAPE.
- Connect the oscilloscope(CH-1) to H/SW(J261) on the main PCB and trigger in setting the VOL/DIV to 1V range.
- Connect the oscilloscope(CH-2) to video out(C571) on the main PCB and set the VOL/DIV to 500mV range.
- 4) Set the TIME/DIV of oscilloscope to 50us range.
- 5) If press P-CHECK of SVC Remote control "A-PG>>>" is appeared in the display, and PG adjustment signal become $412uS \pm 100uSec$.


4. ASSEMBLY LINE ADJUSTMENT

4.1. DVCO adjustment

- This is for adjustment of VCT3834, crystal oscillator frequency after receiving a company Digital pattern. (PAL: EU05CH, NTSC: 13CH)
- When entering adjustment mode by pressing IN-START button, DVCO adjustment is operating automatically. (T/X doesn't operating occasionally during DVCO adjustment,)

4.2. FOCUS ADJUSTMENT

1). Receive the LG standard pattern(digital pattern, Fig5).



<Fig 5>

- 2). Set the picture condition on 'STANDARD' mode.
- 3)Adjust the focus volume of FBT for the best focus of horizontal line A, vertical line B.

4.3. Purity & Convergence adjustment

4.3.1. PURITY adjustment

- 1) Preparation
 - Receive the RED Raster Pattern for purity adjustment. (P-50CH or N-11CH)
 - ¬E Demagnetize the CPT and Cabinet with a degaussing coil

 coil
- 2) Adjustment
 - Pre-adjust the static convergence(STC) with 4 and 6-pole magnet.
 - ¤Ł Push the DY(deflection Yoke)all the way to the CPT panel.
 - □Ø Turn the purity magnet(2-pole magnet) so that the 'green' portion of left side and the 'blue' portion of right side have same portion.
 - ace Pull the DY slowly and fix it when the whole screen become red.

4.3.2. Convergence adjustment

- 1) Preparation
 - Receive the cross Hatch pattern for convergence adjustment.(P-07CH or N-09CH)
 - ¤Ł Let the contrast at the adequate luminance level.

2) Adjustment

- Converge the RED vertical line and BLUE vertical line the same line by changing the angle between the 2 tab of the 4pole magnet.
- ¤Ł Converge the RED horizontal line and BLUE horizontal line in the same line by turning the table of the 4 pole magnet. This time, go not change the angle between the 2 tabs.
- □ Converge the R, G, B horizontal line in the same line by turning the 2 tabs of the 6 pole magnet. This time, do not change the angle between the 2 tabs.

| CONVERGENCE SPEC. | | | | TES | T POSITI | ION | | | |
|--|---|-----|-----|-----|----------|-----|----|---|---|
| POSITIO | N | 29 | 21 | | | | | | |
| С | * | - | - | | 10 | | 12 | | 2 |
| L,R,X,Y | * | 0.8 | 0.8 | | | Α | Х | В | |
| A,B,D,E | * | 0.8 | 0.8 | | | | | | |
| 3,6,9,12 | * | 1.0 | 1.0 | | 9 | L | С | R | 3 |
| 2,4,8,10 | * | 1.4 | 1.4 | | | D | R | E | |
| * : R/B,R/G,B/G <unit: mm=""></unit:> | | | 8 | | 6 | | 4 | | |

<Table 1> Convergence Spec. & Test Position

4.4. Screen Voltage adjustment

- Receive the PAL or SECAM(NTSC) signal into RF mode regardless of channel.
- If you press the ADJ button in LINE SVC mode(IN-START button), the LINE SVC mode changes to screen adjustment mode.
- Turn the Screen Volume of FBT to changes luminance of White signal center as shown below.
- 4) Press the EXIT button to exit SVC mode.

| CPT & INCH | Luminance(Manual Adj.) | Luminance(Auto Adj.) | Description |
|------------|------------------------|----------------------|-------------|
| 29"FLAT | 9 ± 1 FL | 27 Cd | KZ Model |
| 21"FLAT | 12 ± 1 FL | 42 Cd | KZ Model |
| 29"FLAT | 9 ± 1 FL | 27 Cd | KF Model |
| 21"FLAT | 12 ± 1 FL | 42 Cd | KF Model |

<Table 2> Screen Voltage Adjust Spec.

4.5 White Balance adjustment

4.5.1 Necessary Instrument

- 1) Auto White Balance Meter
- 2) Color Analyzer (CA-100)
- 3) Factory Remote control
- * Prior to this adjustment, the Screen Voltage Adjustment must be finished.

4.5.2 Adjustment

- Make the picture luminance 35Ft-L by changing the "CONTRAST" and "BRIGHTNESS".
- Enter the white balance adjust mode with a factory remote control.
- 3) Adjust HIGH Light status of WDR R, WDR B.
- 4) Make the picture luminance 4.5Ft-L by changing the 'contrast' and 'brightness'.

- 5) Adjust LOW Light status of CUT R CUT B at CUT B.
- 6) Repeat 1) ~ 5) until both low and high light have same color temperature.

| | EU | Non-EU |
|-------|------|--------|
| Х | 288 | 268 |
| Υ | 295 | 273 |
| Temp. | 9000 | 13000 |

<Table 3> white Balance Adjust Spec.

- * Note: When adjusting White balance automatically, connect the adjustment JIG in SVC mode. (When pressing IN-START, MUTE button on remote control for adjustment orderly, it changes to SVC mode and screen displays SVC.)
- * WHITE BALANCE INITIAL VALUE CR,CG,CB => 80 WR,WG,WB => 800

4.6. Deflection data adjustment

4.6.1. Preparation

- At adjustment mode (IN-START button on remote control of adjustment), changed to LINE SVC 2 mode to adjust the deflection.
- Press Channel UP/DOWN button for desirous function adjustment.
- 3) Press Volume UP/DOWN button to adjust the data.
- 4) Tune the TV set to receive a Digital pattern.(PAL: EU05CH, NTSC:13CH)

4.6.2. Deflection setting data adjustment

* Note: First, adjust deflection at N50Hz, W50Hz, Z50Hz of PAL signal.

Then adjust deflection at N60Hz, W60Hz, Z60Hz of NTSC signal.

In case of NTSC only model, adjust deflection at N60Hz, W60Hz, Z60Hz of NTSC signal

- When adjusting a deflection, adjust N50Hz of PAL signal first and adjust a deflection at W50Hz, Z50Hz,N50Hz, W60Hz, Z60Hz of PAL signal.
- ¤ŁAdust a deflection as shown below

PAL 4:3 -> PAL 16:9 -> PAL ZOOM -> NTSC 16:9 -> NTSC ZOOM

□Ø After finishing deflection adjustment, press the ENTER button to enter or exit in SVC mode.

1) VA (Vertical Amplitude)

Adjust so that the circle of a digital circle pattern may be located within the effective screen of the CPT.

2) VL (Vertical Linearity)

Adjust so that the boundary line between upper and lower half is in accord with geometric horizontal center of the CPT

3) SC (Vertical S-Correction)

Adjust so that all distance between each horizontal lines are to be the same.

4) VS (Vertical Shift)


Adjust so that the horizontal center line of a digital circle pattern is in accord with geometric center of the CPT.

5) HS (Horizontal Shift)

Adjust so that the vertical center line of a digital circle pattern is in accord with geometric vertical center of the CPT.

6) EW (East-West Width)

Adjust so that a digital circle pattern looks like exact.



7) ET (East-West Trapezium)

Adjust to make the length of top horizontal line same with it of the bottom horizontal line.

8) EP (East-West Parabola)

Adjust so that middle portion of the outermost left and right vertical line looks like parallel with vertical lines of the CPT.

9) ES (East-West Symmetric)

Adjust until the upper and lower corner of the screen symmetric.

10) EC (East-West Corner)

After completing the EP adjustment, adjust so that the corner vertical line to be straight.

11) BOW

Adjust the left and right crooked line on upper and lower side.

12) ANGLE

Adjust the vertical slope.

<Table 4> Initial deflection data & conversion data for each mode (Line SVC-2) (50Hz is initial data and the other data are compensated conversion.)

| OPTION | CONTENTS | DANCE | N50Hz | | |
|--------|---------------------------|-----------|-------|------|--|
| OPTION | CONTENTS | RANGE | 21" | 29" | |
| VA | Vertical Amplitude | 0050~00CF | 00A1 | 160 | |
| VL | Vertical - Linearity | 0025~00BF | 00FB | 0 | |
| SC | S - Correction | 0000~009F | 00D0 | -32 | |
| VS | Vertical Shift | 0600~0900 | 0738 | -224 | |
| HS | Horizontal Shift | 0000~003F | 0017 | 39 | |
| EW | East - West Width | 0400~0EFF | 0B04 | 464 | |
| ET | East - West Trapezium | 0700~08FF | 07F8 | 20 | |
| EP | East - West Parabola | 06E0~0840 | 07B0 | 66 | |
| ES | East - West Symmetric | 06A0~0AFF | 0840 | 0 | |
| EC | East - West corner | 0790~08E0 | 0825 | 48 | |
| BOW | Bow Correction(Quadratic) | -256~255 | 0000 | 0 | |
| ANGLE | Angle Correction(Linear) | -256~255 | 0000 | 0 | |

5. SVC Dat & PSM,SSM Setting Data

Picture Setting Data (LINE SVC-3): No need of adjustment

<Table 5>

| ODTION | CONTENTS | RANGE | 21" | 29" |
|--------|--------------------------|------------|------|------|
| OPTION | CONTENTS | RANGE | FLAT | FLAT |
| DVCO | Digital VCO | -2048~2047 | 00A1 | 160 |
| BCLTH | BCL TRERHOLD | 0~2047 | 00FB | 0 |
| BCLTM | BCL TIME | 0~15 | 00D0 | -32 |
| BCLGN | BCL GAIN | 0~15 | 0738 | -224 |
| SVG1 | SVM GAIN | 0~1FFH | 0017 | 39 |
| SVDEL | SVM DELAY | 0~6 | 0B04 | 464 |
| SVD1 | SVM DELAY1 | 0~6 | 07F8 | 20 |
| LDLY1 | L DELAY | | 07B0 | 66 |
| DSCC | Discharge Sample Count | | 0840 | 0 |
| DSCV | Vertical Discharge Value | | 0825 | 48 |
| HBSO | BLACK CURRENT | 0~511 | 0000 | 0 |
| VBSO | WHITE CURRENT | 0~511 | 0000 | 0 |

<Table 6> Picture Mode Initial Setting Value

| Mode | DYNAMIC | STANDARD | MILD | GAME |
|-----------|---------|----------|------|------|
| CONTRAST | 100 | 90 | 60 | 50 |
| BRIGHT | 60 | 50 | 60 | 60 |
| COLOR | 60 | 50 | 40 | 40 |
| SHARPNESS | 50 | 40 | 30 | 30 |

Shipment Condition

In the last assembly line before packing, below setting are should be made (Using IN-STOP KEY) $\,$


<TAble 7>

| No. | CONTENTS | CONDITION | REMARK |
|-----|----------------|------------------|------------|
| 1 | POWER | OFF | |
| 2 | TV / AV INPUT | TV | |
| 3 | MEMORY CHANNEL | Refer CH. Memory | |
| | | spec. sheet | |
| 4 | SOUND | 30 STEPS | |
| 5 | MUTE | OFF | |
| 6 | DBS | OFF | |
| 7 | PSM | DYNAMIC | |
| 8 | SSM | FLAT | |
| 9 | CHILD LOCK | OFF | |
| 10 | AUTO SLEEP | OFF | |
| 11 | AVL | OFF | |
| 12 | BALANCE | 0 | |
| 13 | BLUE BACK | OFF | |
| 14 | TILT | 0 | 29" Option |

6. Option Adjustment

6.1. Preparation for Adjustment

- This decides function in accordance with model.
 Press the SVC TX adjustment button (IN-START button) at SVC model, then adjust the option at OPTION 1, 2, 3 mode.
- 2) Mark the option adjustment data like (90, 96, 4) in B.O.M.



Mark of BOM

| LEVEL | PART NO. | SPECIFICATION | DESCRIPTION | JOP EXP. |
|-------|-------------|---------------|--------------|-----------|
| 1 | 3141VMNN40A | MAIN, MV033A | CHASSIS ASSY | (90,96,4) |

The OPTION 1 data is 90, the OPTION 2 data is 96, the OPTION 3 data is 4 in this model.

6.2. Adjustment

6.2.1. Adjustment Method

- 1) Input data directly by the buttons corresponded with OPTION 1 ??(0~255), OPTION 2 ??(0~255), OPTION 1 ??(0~255).
- Select each OPTION function by the CH/DOWN button and then set up each OPTION by th VOL UP/DOWN button.

6.2.2 OPTION-1 Function

| OPTION | CODE | FUNCTION | REMARK |
|------------|------|-----------------------------|--------|
| SCART | 0 | PHONE JACK | |
| | 1 | SCART JACK | |
| TOP | 0 | W/O TOP (FLOP BASIC) | |
| (TELETEXT) | 1 | WITH TOP (Only applied some | |
| | | EU nation with TOP) | |
| ACMS | 0 | WITHOUT ACMS FUNCTION | |
| | 1 | WITH ACMS FUNCTION | |
| CH+AU | 0 | ALL NATION | |
| | 1 | CHINA & AUSTRALIA ONLY | |
| DEG | 0 | WITHOUT DEGAUSSING | 21" |
| | 1 | WITH DEGAUSSING | Option |
| TILT | 0 | W/O TILT(NORMAL MODEL, | |
| | | EXCEPT AUSTRALIA) | |
| | 1 | WITH TILT (FLAT AUSTRALIA | |
| | | NORMAL MODEL) | |
| SYS | 0 | B/G, I DK, L/L' | |
| | 1 | B/G, I, DK | |
| | 2 | M | |
| | 3 | PAL-N/M M | |


6.2.3. OPTION-2 Function


| OPTION | CODE | FUNCTION | REMARK |
|-------------|-------|------------------------------|------------|
| TSS (Turbo | 0 | WITHOUT TURBO SEARCH | |
| search) | 1 | WITH TURBO SEARCH | |
| DUAL | 0 | NO SAVE DUAL/SOUND CONDITION | EU |
| (Dual Save) | 1 | SAVE DUAL/SOUND CONDITION | NON EU |
| V-CUR | 0 | NORMAL VOLUME | |
| (Vol.) | 1 | CURVE | NON EU |
| HOTEL | 0 | WITHOUT HOTEL OPTION | |
| | 1 | WITH HOTEL OPTION | |
| M-VOL | 1~100 | MAX | with HOTEL |
| MONO | 0 | FORCED MONO NO SETTING | |
| | 1 | FORCED MONO SETTING | |


6.2.4. OPTION-3 Function

| OPTION | CODE | FUNCTION | REMARK |
|--------|------|--|---------|
| OSD | 0 | ENGLISH Only | EU |
| LANG | 1 | ENGLISH, GERMANY, FRENCH, | VERSION |
| | | ITALIAN,SPANISH, RUSSIAN | |
| | 0 | ENGLISH Only | ARAB |
| | 1 | ENGLISH, FRENCH, ARABIC, URDU | VERSION |
| TXT | 0 | WEST EU (Eng / Fre / Swedish / Czech / | |
| LANG | | German / Spanish / Italian) | |
| | 1 | EAST EU (Polish/ Fre/ Swedish/ Czech/ | EU |
| | | Slovenian/ Ita/ Rumanian) | VERSION |
| | 2 | TURKEY (Eng/ Fre/ Swedish/ Turkish/ | |
| | | German/ Spanish/ Italian) | |
| | 3 | CYILLIC3 (Eng/ Russian/ Estonian/ Czech/ | |
| | | Ger/ Ukrainian/ Lettish) | |
| | 4 | GREEK3(Eng/ Fre/ Swedish/ Turkish/ Ger/ | |
| | | Spanish/ Italian/ Greek) | |
| | 5 | RESERVED | |
| | 0 | WEST EU (Eng/ Fre/ Swedish/ Czech/ | |
| | | German/ Spanish/ italian) | |
| | 1 | EAST EU (Polish/ Fre/ Swedish/ Czech/ | |
| | | Slovakian/ Italian/ Rumania) | ARAB |
| | 2 | TURKEY (Eng/ Fre/ Swedish/ Turkish/ | VERSION |
| | | German/ Spanish/ Italian) | |
| | 3 | CYILLIC3 (Eng/ Russian/ Estonian/ Czech/ | |
| | | German/ Ukrainian/ Lettish) | |
| | 4 | ARAB/ ENGLISH (Eng/ Fre/ Turkish/ Arab) | |
| | 5 | RESERVED | |

BLOCK DIAGRAM










TROUBLE SHOOTING

NO Play Of VCR, DVD






NO Sound / Picture OK



NO Picture / SOUND OK



NO Play Of VCR, DVD

