



(2) Condition code setting and confirmation

Condition codes are made up of 3-digit numerals. Follow the procedure below to set a code.






1. While D appears: while pushing F, push the CODE key. The current condition code is displayed.



2. Enter numeral keys using the keyboard. Enter in order from the first to last digit. Entering more than 3 digits will overwrite previously entered digits.

NOTE: Only numeral digits may be entered.




3. Push the ANS key or PTT to return to the beginning display.



4. To clear a condition code while entering or to clear the existing code, while pushing the F key, push the C key.

3-2 LCD



- ① **L** Appears when transmit output power is set to low.
- ② **TSQ** Appears while the tone encoder/tone squelch is set.
- ③ **+** [+] or [-] appear when transmit frequency offsets are set.
- ④ **B** Appears during a low battery condition.
- ⑤ **M188** Indicates the memory channel number.
- ⑥ **BUSY** Appears when the squelch is open.
- ⑦ **.** Transmit/receive frequency decimal point (MHz). Flashes during scan.