


TUNER-UNIT BR016920B (6001-6999)

TO CNTL-UNIT (J3014)



TO MAIN-UNIT
(J1014) (white)

TO MAIN-UNIT
(J1014) (white)

TO PA-A-UNIT
(J5006)


TO MAIN-UNIT (J1011)

TO CNTL-UNIT (J3014)

DC IN 13.8V


DC IN 13.6V

TO CNTL-UNIT (J3001)



PA-A-UNIT
BR014630D (5000-5499)

TO TUNER-UNIT (J5004)




DSP-UNIT BR016930B (7501-7999)


④

TO MAIN-UNIT
[reg-J1021]

TO CNTL-UNIT
[J3011]




⑤



-6
-1
20
10
0

6

MAIN-UNIT BR016880B (1000-1999)



TO TUNER UNIT (J3021)

TO DSP UNIT (J3021)

TO TUNER UNIT (J3021)

TO TUNER UNIT (J3021)

TO CNTL UNIT (J3018)

TO CNTL UNIT (J3018)

TO MIC UNIT (J3020)

TO MIC UNIT (J3020)

TO CNTL UNIT (J3020)


TO CNTL UNIT (J3020)

TO CNTL UNIT (J3020)

TO CNTL UNIT (J3020)

FT-950 BLOCK-DIAGRAM

7



(8)
CONNECTION DIAGRAM

