


brother[®]

COLOUR TV SERVICE MANUAL

10


CAUTION

BEFORE SERVICING THE CHASSIS, READ THE "SAFETY PRECAUTIONS" IN THIS MANUAL.



CHASSIS: PC-04A(CBT-2168E)


MODEL: BR 7121




CHASSIS: PC-04A(CBZ-9745E)

MODEL: BR 7120



WIRING DIAGRAM




TX SCHEMATIC DIAGRAM




PRE-AMP



BLOCK DIAGRAM



PARTS LOCATION OF MAIN CHASSIS



TXT P.C.BOARD (COMPONENT SIDE)(Not in use)

