

AV28BT7ENS / AV28BT7ENB
 AV28BT7EES / AV28BT7EEB
 AV28BT7EPS / AV28BT7EPB

SETTING OF THE LAST MEMORY FOR SHIPMENT

■ USER SETTING VALUES

Setting Item	Setting Value	Setting Item	Setting Value
SOUND MENU		FEATURE MENU	
BASS	CENTER	SLEEP TIMER	OFF
TREBLE	↑	CHILD LOCK	OFF
BALANCE	↑		
EFFECT	OFF		
PICTURE MENU		INSTALL-> TV CONFIG. MENU	
BRIGHTNESS	These adjust are automatically restored when APS bit in Service menu is set.	LANGUAGE	ENGLISH
COLOUR		COUNTRY	?
CONTRAST		AV-2 OUTPUT	TV
SHARPNESS	The procedure for setting APS bit is described bellow.		
HUE (only NTSC)			
PICTURE MODE	AUTO		


■ SETTING APS BIT IN SERVICE MENU

- 1) Enter service menu in TV mode by pressing "INFO" and "MUTING" keys simultaneously. Service Menu will appear.
- 2) Select OPTIONS by pressing Up/Down keys on remote control unit.
- 3) Enter OPTIONS by pressing Left/Right keys on remote control unit.
- 4) Select OPTION 8 by pressing Up/Down keys on remote control unit.
- 5) Selected bit in one OPTION is shown by blinking character. Select B2 by pressing Left/Right keys on remote control unit.
DO NOT CHANGE ANY OTHER BIT.
- 6) Press digit key "1" to set APS bit.
- 7) Press "STANDARD" key on remote control unit to exit service mode.

AV28BT7ENS / AV28BT7ENB
AV28BT7EES / AV28BT7EEB
AV28BT7EPS / AV28BT7EPB

AV28BT7ENS / AV28BT7ENB
AV28BT7EES / AV28BT7EEB
AV28BT7EPS / AV28BT7EPB

CIRCUIT DIAGRAMS MAIN PWB CIRCUIT DIAGRAM




MAIN PWB
VE-20073447(AV28BT7EES/EEB) VE-20073586(AV28BT7ENS/ENB) VE-20071473(AV28BT7EPS/EPB)

AV28BT7ENS / AV28BT7ENB
AV28BT7EES / AV28BT7EEB
AV28BT7EPS / AV28BT7EPB

AV28BT7ENS / AV28BT7ENB
AV28BT7EES / AV28BT7EEB
AV28BT7EPS / AV28BT7EPB

MULTISOUND PWB CIRCUIT DIAGRAM




MULTISOUND PWB
VE-20078991(AV28BT7ENS/ENB, AV28BT7EES/EEB)
VE-20079020(AV28BT7EPS/EPB)


AV28BT7ENS / AV28BT7ENB
AV28BT7EES / AV28BT7EEB
AV28BT7EPS / AV28BT7EPB

AV28BT7ENS / AV28BT7ENB
AV28BT7EES / AV28BT7EEB
AV28BT7EPS / AV28BT7EPB

CRT SOCKET PWB CIRCUIT DIAGRAM




FRONT AV + HEAD PHONE JACK PWB CIRCUIT DIAGRAM



No.51883

FRONT CONTROL PWB CIRCUIT DIAGRAM



2-9

2-10

No.51883