








# SCHEMATIC DIAGRAM

PRIMA


PRESELECTION BOARD (for without remote control)




REMOTE CONTROL TRANSMITTER BOARD



PREAMPLIFIER BOARD



CHANNEL SELECTOR AND REMOTE CONTROL RECEIVER BOARD



# SCHEMATIC DIAGRAM

# 'PRIMA'

# AUDIO TON

