


9-1 Cassette Deck



Schematic Diagrams
9-2 Option



FROM TAP		MAIN		WCW2
(2)	MCK	(4)	MDAT	(6)
(3)	MLT	(5)	MUTE	(7)
(4)	SGDT	(6)	SGCK	(8)
(5)	XRST	(7)	XRS1	(9)
(6)	LKFS	(8)	FOK ON	(10)
(7)	LS1A	(9)	LS1B	(11)
(8)	CLOSE	(10)	OPEN	(12)
(9)	OP S/M	(11)	CL S/M	(13)
(10)	MCK	(12)	MDAT	(14)
(11)	MLAT	(13)	MLAT	(15)
(12)	DATA	(14)	DATA	(16)
(13)	LAT	(15)	RESET	(17)
(14)	DOUBLE	(16)	DOUBLE	(18)
(15)	EMPH	(17)	SEL3	(19)



9-4 Video CD

