

NOTES :

1. REFER TO PARTS LIST FOR COMPONENT VALUES

(0195)